

Likorall

242/243/250

Quick Reference Guide





Safety Instructions

- · Read the instruction guides for the lift and lifting accessories before use.
- Before the patient is lifted from the underlying surface, but after the straps have been fully extended, make sure the straps are properly connected to the sling bar.
- Max. load Likorall 242: 200 kg (440 lbs). Max. load Likorall 243: 230 kg (507 lbs). Max. load Likorall 250: 250 kg (550 lbs).

To retain max. load it is essential to use accessories rated for the same max. load or greater.


☐i IMPORTANT!

This quick reference guide does not replace the lift's instruction guide, which can be downloaded from www.liko.com.


1 Hand Control



HandControl IR:



2 Emergency Lowering/Raising (Electrical)



3 Mechanical Emergency Lowering

Exclusively: 242 S, ES



Activate:

Press down repeatedly on the emergency lowering handle.





Reset:

Remove load from the lift strap. Hold the emergency lowering handle down at the half-way position while at the same time turning the black knob clockwise.

4 Emergency Stop

Activate:





5 SSP Limit Switch

Reset:



Cleaning

Ergonomics

When necessary, clean the lift with a moist cloth, using common surface cleaners or disinfectants.

· Never lift manually - let the lift do the lifting.

· Take it easy. Work calmly and methodically.

· Don't strain your back! Work in a walking stance

Use the bed's raising and lowering functions.

Reduce the lever effect. Work close to the

Simple Troubleshooting

with your back straight.

patient and the lift.

Check to ensure that:

- · emergency stop is not pressed in
- · the battery is charged
- · the hand control is properly connected
- · the mechanical emergency lowering device has been reset.

Other Quick Reference Guides

Quick reference guides for Liko's lifts and slings are available for downloading from www.liko.com.

© Copyright Liko AB







Charging of Batteries



- · Charge the lift regularly after
- · The lift does not function during charging.

The lifting motion is interrupted when load on the

lift strap is biased or when the lift strap is twisted.

6. The R2R sling bar has hooks for two lift straps to enable transfer between two lifts.

7. A sling bar with a Quick-release Hook enables

7 Sling Bar Connection

fast and easy exchange of sling bars.

· Ensure that the emergency stop is not pressed in during charging.



www.liko.com

Manufacturer:

Liko AB SE-975 92 Luleå Sweden info@liko.se